

[LAB] Tester: Zoyi ZT-DQ02 LCR



- Manual
- Firmware
- Software PC

Firmware Upgrade

1. While the device is powered off, press and hold the X/D/Q key, then simultaneously press the power button until the screen displays "USBBoot."
2. Connect the device to a computer using a TYPE-C data cable. The computer will recognize it as an LCR disk.
3. Copy the prepared firmware upgrade file into the LCR disk. The device will automatically start the upgrade process. Do not perform any operations during the upgrade.
4. Once the upgrade is complete, the screen will automatically switch to the measurement interface, indicating a successful upgrade.

Battery Charging

Cuando el icono de la batería muestra solo 2 rayas rojas es momento de cargar la batería interna. Seguir estos pasos:

1. Insert the included TYPE-C data cable and connect it to a DC 5V output adapter to charge.
2. During normal charging, the charging indicator light will be red.
3. Once fully charged, the charging indicator light will turn green.

From:

<https://euloxio.myds.me/dokuwiki/> - Euloxio wiki

Permanent link:

https://euloxio.myds.me/dokuwiki/doku.php/doc:tec:lab:tester:lab_ztdq02:inicio?rev=1784117275

Last update: 2026/07/15 14:07

